

SCO Unix Openserver V5.0 driver installation procedure

2100sco.Z FILE EXTRACTION AND EXECUTION:

You need to uncompress the diskette image file (2100sco.Z).

```
uncompress 2100sco
```

Copy the diskette image file (2100sco) to the diskette using the dd command.

```
dd if=2100sco of=/dev/rfd0135ds18
```

Now run the installpkg utility to install driver.

```
installpkg
```